


User Manual
English

Stratos MS A405

O₂ Measurement



About This Manual	5
Documents Supplied	6
Introduction	7
Overview of the Stratos MS	8
Package Contents.....	8
Mounting Accessories	9
Pipe Mounting, Protective Hood	10
Panel Mounting	11
Terminal Assignments, Rating Plates.....	12
Power Supply	13
Start-Up	14
Calibration and Maintenance in the Lab	14
Memosens Cable	15
Measuring Mode.....	17
The Keys and Their Functions	18
Signal Colors (Display Backlighting).....	19
The Display.....	19
Display in Measuring Mode	20
Selecting the Mode / Entering Values	21
Operating Modes	22
HOLD Mode.....	23
Operating Modes / Functions	24
Connecting a Memosens Sensor	26
Replacing a Sensor.....	27
Configuration: Overview.....	28
Configuration.....	30
Sensor Verification (TAG, GROUP)	32
Output Current: Range, Current Start/End.....	34
Output Current: Time Averaging Filter	36
Output Current: Error and HOLD	38
Output Current: Alarm Delay, Sensocheck.....	40
Salinity Correction, Pressure Correction	42

Relay Contacts: Function Assignment, Limit Values	44
Relay Contacts: Limit Function, Hysteresis.....	46
Relay Contacts: Alarm.....	48
Relay Contacts: Controlling a Rinsing Probe	50
Protective Wiring of Relay Contacts.....	52
Time and Date, Measuring Point (TAG/GROUP)	54
Calibration	56
Common Combination:	
Process Variable / Calibration Mode.....	57
Slope Calibration in Air.....	58
Slope Calibration in Water.....	59
Zero Calibration	60
Product Calibration.....	62
Temp Probe Adjustment.....	64
Measurement.....	65
Diagnostics	66
Service	71
Error Messages.....	74
Sensocheck and Sensoface	76
Operating States.....	77
Product Range	78
Specifications.....	79
Index.....	83

Subject to change without notice

Return of Products Under Warranty

Please contact our Service Team before returning a defective device.

Ship the cleaned device to the address you have been given.

If the device has been in contact with process fluids, it must be decontaminated/ disinfected before shipment. In that case, please attach a corresponding certificate, for the health and safety of our service personnel.

Disposal


Please observe the applicable local or national regulations concerning the disposal of “waste electrical and electronic equipment”.

About This Manual:

This manual is intended as a reference guide to your device – You don't have to read the book from front to back.

Take a look at the **Table of Contents** or the **Index** to find the function you are interested in. Each topic is explained on a double-page spread with step-by-step instructions on how to configure the desired function. Clearly legible page numbers and headlines help you to quickly find the information:

Left page:
How do I get to the function



Parameter concerned

Right page:
Which settings are provided for this function

Safety Instructions

In official EU languages and others

Quickstart Guides

Installation and first steps:

- Operation
- Menu structure
- Calibration
- Error messages and recommended actions

Specific Test Report

Electronic Documentation

Manuals + Software

Ex Devices:

Control Drawings

EU Declarations of Conformity

Up-to date documentation available on our website:



Stratos MS is a 4-wire analyzer for use with Memosens sensors. The Model A405B allows applications in hazardous-area Zone 2. Current is provided through a universal power supply 80 ... 230 V AC, 45 ... 65 Hz / 24 ... 60 V DC. The analyzer provides two 0 (4) 20 mA current outputs for transmission of measured value and temperature, for example. Two floating relay contacts are available for free configuration.

You can select one of the following measuring functions:

- pH
- ORP
- Dissolved oxygen
- Conductivity measurement (conductive/inductive)

Enclosure and mounting possibilities

- The sturdy molded enclosure is rated IP 67/NEMA 4X outdoor.
Material of front unit: PBT, rear unit: PC.
Dimensions: H 148 mm, W 148 mm, D 117 mm.
It is provided with knockouts to allow:
 - panel mounting (138 mm x 138 mm cutout to DIN 43700)
 - wall mounting (with sealing plugs to seal the enclosure)
 - post/pipe mounting (dia. 40 ... 60 mm, □ 30 ... 45 mm)

Protective hood (accessory)

The protective hood provides additional protection against direct weather exposure and mechanical damage (available as accessory).

Connection of sensors, cable glands

For connecting the cables, the enclosure provides

- 3 knockouts for cable glands M20x1.5
- 2 knockouts for NPT 1/2" or rigid metallic conduit

Memosens sensors and connecting cables

Please visit our website for more information on our product range: www.knick.de.

Package Contents

Check the shipment for transport damage and completeness.

The package should contain:

Front unit, rear unit, bag containing small parts

Specific test report

Documentation





Fig.: Assembling the enclosure

- | | |
|--|--|
| 1) Jumper (3 x) | 6) Sealing insert (1 x) |
| 2) Washer (1 x), for conduit mounting:
Place washer between enclosure and nut | 7) Rubber reducer (1 x) |
| 3) Cable tie (3 x) | 8) Cable gland, M20x1.5 (3 x) |
| 4) Hinge pin (1 x), insertable from either side | 9) Filler plug (3 x) |
| 5) Enclosure screw (4 x) | 10) Hexagon nut (5 x) |
| | 11) Sealing plug (2 x), for sealing in case of wall mounting |

Mounting Plan, Dimensions



All dimensions in mm


Mounting Accessories

Pipe-mount kit, accessory ZU 0274

Protective hood for wall and pipe mounting, accessory ZU 0737

Panel-mount kit, accessory ZU 0738

Pipe Mounting, Protective Hood



- 1) Hose clamp with worm gear drive to DIN 3017 (2 x)
- 2) Pipe-mount plate (1 x)
- 3) For vertical or horizontal posts or pipes
- 4) Self-tapping screw (4 x)

Fig.: Pipe-mount kit, accessory ZU 0274





Fig.: Protective hood for wall and pipe mounting, accessory ZU 0737

Panel Mounting




- 1) Circumferential sealing (1 x)
- 2) Screw (4 x)
- 3) Position of control panel
- 4) Span piece (4 x)
- 5) Threaded sleeve (4 x)

Cutout
138 x 138 mm (DIN 43700)

Fig.: Panel-mount kit, accessory ZU 0738


Overview of the Stratos MS

Memosens



Terminal Assignments, Rating Plates

The terminals are suitable for single or stranded wires up to 2.5 mm² (AWG 14).



Knick >

A4*5N

No. 84194/0000000/1233

Power

80 (-15%) to 230 (+10%) V AC,
45 to 65 Hz, < 15 VA

24 (-15%) to 60 (+10%) V DC,
= 10 W

-20 ≤ T_a ≤ +55°C

Enclosure Type 4X

D-14163 Berlin Made in Germany

⚠️ ☐ CE


Application in Hazardous Locations



When using the device in a hazardous location, observe the specifications of the Control Drawing.

Power Supply

Connect the power supply for Stratos MS to terminals 21 and 22
(80 ... 230 V AC, 45 ... 65 Hz / 24 ... 60 V DC)



Connection of Memosens sensor		
1	Brown	+3 V
2	Green	RS 485 A
3	Yellow	RS 485 B
4	White/Transp.	GND/shield

Figure:
Terminals, device opened,
back of front unit

Terminal assignments

Memosens connection		
1 (BN)	+3 V	Brown
2 (GN)	RS 485 A	Green
3 (YE)	RS 485 B	Yellow
4 (WH/CL)	GND/ shield	White / Transp.
5	do not connect	
6	do not connect	
7	do not connect	
Current outputs OUT1, OUT2		
8	+ Out 2	
9	- Out 1 / Out 2	
10	+ Out 1	
11	HOLD	
12	HOLD	
13	do not connect	
Relay contacts REL1, REL2		
14	REL 1	
15	REL 1/2	
16	REL 2	
17	do not connect	
18	do not connect	
19	do not connect	
20	do not connect	
Power supply		
21	power	
22	power	

Start-Up

When a Memosens sensor is connected, the appropriate measuring function (device type) is automatically loaded.

Changing the Measuring Function

In the "Service" menu you can select another measuring function at any time.

Calibration and Maintenance in the Lab

The "MemoSuite" software allows calibrating Memosens sensors under reproducible conditions at a PC in the lab. The sensor parameters are registered in a database. Documenting and archiving meet the demands of FDA CFR 21 Part 11. Detailed reports can be output as csv export for Excel. MemoSuite is available as accessory and comes in the versions "Basic" and "Advanced": www.knick.de.

Settings and specifications

Currently connected sensor:
Sensor type, manufacturer, order code and serial number

Function selection
(The selected function is highlighted.)

Parameters of currently connected sensor

Last calibration (adjustment)

Measured values		Sensor data	
Oxygen current	-141 nA	Sensor type:	Oxygen
Oxygen current (25°C)	-143 nA	Manufacturer:	KNICK
Temperature	24.5 °C	Order code:	SE 715/1-MS
Partial pressure	214.3 hPa	Serial number:	1029852
Percent saturation (water)	104.3 %air	Adjustment data	
Concentration (water)	7.571 ppm	Date:	06/29/2011 11:22:56
Oxygen content (gas)	21.19 %vol	Slope:	-137 nA
		Zero point:	0.00 nA

Measured values


Oxygen current

-141 nA

Oxygen current (25°C) -143 nA

Display size of measured values
When the cursor moves over a measured value, it changes to a magnifying glass, allowing to magnify the measured-value display at a mouse click.

Memosens Cable



Specifications

Material	TPE
Cable diameter	6.3 mm
Length	up to 100 m
Process temperature	-20 °C ... +135 °C / -4 ... +275 °F
Ingress protection	IP 68

Order Codes


	Cable type	Cable length	Order number
Memosens	Ferrules	3 m	CA/MS-003NAA
		5 m	CA/MS-005NAA
		10 m	CA/MS-010NAA
		20 m	CA/MS-020NAA
		M12 plug, 8-pin	3 m
5 m	CA/MS-005NCA		
Memosens Ex*	Ferrules	3 m	CA/MS-003XAA
		5 m	CA/MS-005XAA
		10 m	CA/MS-010XAA
		20 m	CA/MS-020XAA
	M12 plug, 8-pin	3 m	CA/MS-003XCA
		5 m	CA/MS-005XCA

Other cable lengths or cable types are available on request.

* Ex-certified ATEX II 1G Ex ia IIC T3/T4/T6 Ga

Measuring Mode

After the operating voltage has been connected, the analyzer automatically goes to “Measuring” mode. To call the measuring mode from another operating mode (e.g., Diagnostics, Service): Hold **meas** key depressed (> 2 s).



Depending on the configuration, you can set various displays as standard display for the measuring mode (see page 20).

Note: By pressing the **meas** key in measuring mode you can view the displays for approx. 60 sec.



NOTICE:

You must configure the analyzer for the respective measurement task.

Up / Down arrows


- Menu: Increase/decrease a numeral
- Menu: Selection

Left / Right arrows

- Menu: Previous/next menu group
- Number entry: Move between digits

meas

- Return to last menu level
- Directly to measuring mode (press > 2 s)
- Measuring mode: other display (temporarily for approx. 60 s)



info


- Retrieve information
- Show error messages

enter

- Configuration: Confirm entries, next configuration step
- Calibration: Continue program flow

menu


- Measuring mode: Call menu



- | | | | |
|----|--|----|-----------------------|
| 1 | Temperature | 13 | Info available |
| 2 | Sensocheck | 14 | HOLD mode active |
| 3 | Interval/response time | 15 | Primary process value |
| 4 | Sensor data | 16 | Secondary display |
| 5 | Wear | 17 | Proceed using enter |
| 6 | Limit message:
Limit 1  or Limit 2  | 18 | Not used |
| 7 | Alarm | 19 | Diagnostics |
| 8 | Service | 20 | Configuration mode |
| 9 | Not used | 21 | Calibration mode |
| 10 | Calibration | 22 | Measuring mode |
| 11 | Memosens sensor | 23 | Sensoface |
| 12 | Waiting time running | 24 | Unit symbols |

Signal Colors (Display Backlighting)

- | | |
|--------------|--|
| Red | Alarm (in case of fault: display values blink) |
| Red blinking | Input error: illegal value or wrong passcode |



The MAIN DISPLAY is the display which is shown in measuring mode. To call the measuring mode from any other mode, hold the **meas** key depressed for at least 2 sec.

meas key

enter key

meas



By pressing **meas** briefly you can step through further displays such as primary value or tag number (TAG). After 60 sec they switch back to the main display.

After 60 sec they switch back to the main display.

meas



Press **enter** to select a display as MAIN DISPLAY (displayed permanently in measuring mode).

The secondary display shows "MAIN DISPLAY – NO".

approx. 2 s




Use the **UP / DOWN** arrows to select "MAIN DISPLAY – YES" and confirm by pressing **enter**.

This display is now shown in measuring mode.


To select the operating mode:

- 1) Hold **meas** key depressed (> 2 s) (measuring mode)
- 2) Press **menu** key: the selection menu appears
- 3) Select operating mode using left / right arrow key
- 4) Press **enter** to confirm the selected mode



To enter a value:

- 5) Select numeral: left / right arrow
- 6) Change numeral: up / down arrow
- 7) Confirm entry by pressing **enter**



Diagnostics

Display of calibration data, display of sensor data, sensor monitor, performing a device self-test, viewing the logbook entries, display of hardware/software versions of the individual components. The logbook can store 100 events (00...99). They can be displayed directly on the device.

HOLD

Manual activation of HOLD mode, e.g., for replacing a sensor. The signal outputs adopt a defined state. HOLD can also be activated via the external input (see next page).

Calibration

Every sensor has typical characteristic values, which change in the course of the operating time. Calibration is required to supply a correct measured value. The device checks which value the sensor delivers when measuring in a known solution. When there is a deviation, the device can be "adjusted". In that case, the device displays the "actual" value and internally corrects the measurement error of the sensor. Calibration must be repeated at regular intervals. The time between the calibration cycles depends on the load on the sensor. During calibration the device is in HOLD mode.

During calibration the device remains in the HOLD mode until it is stopped by the operator.

Configuration

You must configure the analyzer for the respective measurement task. In the "Configuration" mode you select the connected sensor, the measuring range to be transmitted, and the conditions for warning and alarm messages. During configuration the device is in HOLD mode.

Configuration mode is automatically exited 20 minutes after the last keystroke. The device returns to measuring mode.

Service

Maintenance functions (current source, relay test), assigning passcodes, selecting the device type (pH/oxy/conductivity), resetting to factory settings.

The HOLD mode is a safety state during configuration and calibration. Output current is frozen (LAST) or set to a fixed value (FIX). Alarm and limit contacts are disabled.


HOLD mode, display icon:



Output signal response

- **LAST:** The output current is frozen at its last value. Recommended for short configuration procedures. The process should not change decisively during configuration. Changes are not noticed with this setting!
- **FIX:** The output current is set to a value that is noticeably different from the process value to signal the control system that the device is being worked at.

Output signal during HOLD:




Terminating the HOLD mode

The HOLD mode is exited by switching to measuring mode (hold **meas** key depressed). The display reads "Good Bye". After that, the HOLD mode is exited. When the calibration mode is exited, a confirmation prompt ensures that the installation is ready for operation (e.g.: sensor reinstalled, located in process).

External activation of HOLD

The HOLD mode can be activated from outside by sending a signal to the HOLD input (e.g., from the process control system).

HOLD inactive	0...2 V AC/DC
HOLD active	10...30 V AC/DC






Pressing the **menu** key (down arrow) opens the selection menu. Select the menu group using the left/right arrow keys. Pressing **enter** opens a menu item. Press **meas** to return.

 DIAG	CALDATA	Display of calibration data
	SENSOR	Display of sensor data
	SELFTEST	Self test: RAM, ROM, EEPROM, module
	LOGBOOK	100 events with date and time
	MONITOR	Display of direct sensor values
	VERSION	Display of software version, model designation, serial no.
HOLD	Manual activation of HOLD mode, e.g., for sensor replacement. The signal outputs behave as configured (e.g., last measured value, 21 mA)	
CAL	pH	pH adjustment / ORP adjustment / product calibration
	Oxy	Adjustment (WTR/AIR) / zero adjustment / product cal.
	COND(I)	Adjustment with solution / cell factor input / product cal.
	CAL_RTD	Adjustment of temperature probe
CONF	CONF	Configuration See "Overview of Configuration" on next page.
SERVICE (Access via code, factory setting: 5555)	MONITOR	Display of measured values for validation (simulators)
	OUT1	Current source, output 1
	OUT2	Current source, output 2
	RELAIS	Relay test
	CODES	Specifying access codes for operating modes
	DEVICE TYPE	Selecting the device type
	DEFAULT	Reset to factory setting

The configuration steps are assigned to different menu groups.
 Using the left/right arrow keys, you can jump between the individual menu groups.
 Each menu group contains menu items for setting the parameters.
 Pressing **enter** opens a menu item. Use the arrow keys to edit a value.
 Press **enter** to confirm/save the settings.
 Return to measurement: Hold **meas** key depressed (> 2 s).

Select menu group	Menu group	Code	Display	Select menu item
	Sensor settings	SNS:	Conf [▲] _{SENSOR} [▲] _▲ ⁱ	<p>enter</p> <p>enter</p> <p>enter</p> <p>enter</p>
		Menu item 1		
		:		
		Menu item ...		
▶	Current output 1	OT1:	Conf [▲] _{OUT 1} [▲] _▲ ⁱ	
▶	Current output 2	OT2:	Conf [▲] _{OUT 2} [▲] _▲ ⁱ	
▶	Compensation	COR:	Conf [▲] _{CORRECTION} [▲] _▲ ⁱ	
▶	Alarm mode	ALA:	Conf [▲] _{ALARM} [▲] _▲ ⁱ	
▶	Relay outputs (LIMIT / ALARM / WASH)	REL:	Conf [▲] _{REL 1/REL 2} [▲] _▲ ⁱ	
▶	Setting the clock	CLK:	Conf [▲] _{CLOCK} [▲] _▲ ⁱ	
▶	Tag number	TAG:	Conf [▲] _{TAG} [▲] _▲ ⁱ	

Step	Action/Display	Remark
Connect sensor		When no Memosens sensor is connected, the error message "NO SENSOR" is displayed.
Wait until the sensor data are displayed.		The hourglass in the display blinks.
Check sensor data	 <p data-bbox="384 837 650 933">View sensor information using ◀ ▶ keys, confirm using enter.</p>	Sensoface is friendly when the sensor data are okay.
Go to measuring mode	Press meas , info or enter	After 60 sec the device automatically returns to measuring mode (timeout).
Possible error message		
Sensor defective. Replace sensor		When this error message appears, the sensor cannot be used. Sensoface is sad.

Step	Action/Display	Remark
<p>Select HOLD mode A sensor should only be replaced during HOLD mode to prevent unintended reactions of the outputs or contacts.</p>	<p>Press menu key to call the selection menu, select HOLD using the ◀ ▶ keys, press enter to confirm.</p>	<p>Now the device is in HOLD mode. The HOLD mode can also be activated externally via the HOLD input. During HOLD the output current is frozen at its last value or set to a fixed value.</p>
<p>Disconnect and remove old sensor</p>		
<p>Install and connect new sensor.</p>		<p>Temporary messages which are activated during the replacement are indicated but not output to the alarm contact and not entered in the logbook.</p>
<p>Wait until the sensor data are displayed.</p>		
<p>Check sensor data</p>	 <p>View sensor information using ◀ ▶ keys, press enter to confirm.</p>	<p>You can view the sensor manufacturer and type, serial number and last calibration date.</p>
<p>Check measured values</p>		
<p>Exit HOLD</p>	<p>Hit meas key: Return to the selection menu. Hold meas key depressed: Device switches to measuring mode.</p>	

Configuration (default in bold print)			
Sensor		Oxy	
SNS	MEAS MODE		dO % / dO mg/l / dO ppm / GAS %
	TEMP UNIT		°C / °F
	CAL MODE		CAL AIR / CAL WTR
	CALTIMER		ON / OFF
	ON	CAL-CYCLE	0 ... 9999 h (168 h)
	CHECK TAG		ON / OFF
	CHECK GROUP		ON / OFF

Current output 1			Oxy
OT1	RANGE		4 ... 20 mA / 0 ... 20 mA
	CHANNEL		OXY / TMP
	OXY dO %	BEGIN (0)/4 mA	000.0 ... 600.0 %
		END 20 mA	000.0 ... 600.0 %
	OXY dO / mg/l	BEGIN (0)/4 mA	00.00 mg/l ... 99.99 mg/l
		END 20 mA	00.00 mg/l ... 99.99 mg/l
	OXY dO / ppm	BEGIN (0)/4 mA	00.00 ppm ... 99.99 ppm
		END 20 mA	00.00 ppm ... 99.99 ppm
	OXY GAS / %	BEGIN (0)/4 mA	00.00 ppm ... 99.99 %
		END 20 mA	00.00 ppm ... 99.99 %
	TMP °C	BEGIN (0)/4 mA	-20 ... 150 °C / 000.0 °C
		END 20 mA	-20 ... 150 °C / 100.0 °C
	TMP °F	BEGIN (0)/4 mA	-4 ... 302 °F / 032.0 °F
		END 20 mA	-4 ... 302 °F / 212.0 °F
	FILTERTIME		0...120 SEC / 120 SEC
FAIL 22 mA		ON / OFF	
FACE 22 mA		ON / OFF	
HOLD MODE		LAST / FIX	
FIX	HOLD-FIX	4 ... 22 mA / 021.0 mA	

Current output 2	Default setting CHANNEL: TMP (other settings like OT1)
------------------	---



Configuration (default in bold print)		
Correction		Oxy
COR	SALINITY	00.00 ... 45.00 ppt (00.00 ppt)
	PRESSURE UNIT	BAR / KPA / PSI
	BAR	PRESSURE
	KPA	PRESSURE
	PSI	PRESSURE
0.000 ... 9.999 BAR (1.013 BAR)	000.0 ... 999.9 KPA (100 KPA)	000.0 ... 145.0 PSI (14.5 PSI)
Alarm		Oxy
ALA	DELAYTIME	0 ... 600 s (0010 SEC)
	SENSOCHECK	ON / OFF
Relay 1		
RL1	LIMIT ALARM WASH	The following submenu depends on the selected setting.
LM1	CHANNEL	OXY / TMP
	FUNCTION	Lo LEVL / Hi LEVL
	CONTACT	N/O / N/C
	LEVEL	000.0 % 000.0 ... 600.0 % 00.00 mg/l ... 99.99 mg/l 00.00 ppm ... 99.99 ppm 00.00 ppm ... 99.99 % (-20 ... 150 °C)
	HYSTERESIS	000.0 % / 0 ... 50 % full scale
DELAYTIME	0010 SEC / 0000 ... 9999 s	
AL1	TRIGGER	FAIL / FACE
	CONTACT	N/O / N/C
WS1	CYCLE TIME	000.0 h / 0.0 ... 999.9 h
	DURATION	0060 SEC / 0 ... 1999 s
	RELAX TIME	0030 SEC / 0000 ... 1999 s
	CONTACT	N/O / N/C
Relay 2 Default LIMIT / FUNCTION: Hi LEVL (other settings like Relay 1)		
Time/date		
CLK	FORMAT	24 h / 12 h
	24 h	hh:mm
	12 h	hh:mm (AM / PM) 00 ... 12:59 AM / 1 ... 11:59 PM
	DAY / MONTH	dd.mm
YEAR	2000 ... 2099	
Measuring points (TAG / GROUP)		
TAG	The entries are made in the text line.	A...Z, 0...9, - + < > ? / @
GROUP	The entries are made in the text line.	0000...9999 (0000)

Device Type: Oxy

The device type is automatically selected upon first start-up. In the SERVICE menu you can change the device type. Afterwards, you must select the corresponding calibration mode in the CONF menu.

- 1 Press **menu**.
- 2 Select **CONF** using ◀ ▶, press **enter**.
- 3 Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu, edit using arrow keys (see next page).
Confirm (and proceed) by pressing **enter**.
- 4 Exit: Press **meas** key until the [meas] mode indicator is displayed.

Select measuring mode	enter
Temperature unit	
Calibration medium water/air	
Calibration timer	
CHECK TAG	
CHECK GROUP	

Menu item	Action	Choices
Select measuring mode 	Select measuring mode using ▲ ▼ keys. DO: Measurement in liquids GAS: Measurement in gases Press enter to confirm.	dO % dO mg/l dO ppm GAS %
Temperature unit 	Select °C or °F using ▲ ▼ keys. Press enter to confirm.	°C °F
Air/water as cal medium 	Select calibration medium using ▲ ▼ keys. AIR: Air as calibration medium WTR: Air-saturated water as calibration medium Press enter to confirm.	CAL_AIR CAL_WTR
Calibration Timer 	Adjust CALTIMER using ▲ ▼ : OFF: No timer ON: Fixed cal cycle (adjust in the next step) Press enter to confirm.	OFF/ON (ON: 0 ... 9999 h)

Note for the calibration timer:

When Sensocheck has been activated in the Configuration / Alarm menu, the expiration of the calibration interval is indicated by Sensoface:

 + 	Over 80 % of the calibration interval has already passed.
 + 	The calibration interval has been exceeded.

The time remaining until the next due calibration can be seen in the diagnostics menu (see Diagnostics chapter).

Sensor Verification (TAG, GROUP)

1 Press **menu** key.


2 Select **CONF** using ◀ ▶, press **enter**.

3 Select **SENSOR** menu using ◀ ▶ keys, press **enter**.
All items of this menu group are indicated by the "SNS:" code.
Press **enter** to select menu, edit using arrow keys (see next page).
Confirm (and proceed) by pressing **enter**.

4 Exit: Press **meas** key until the [meas] mode indicator is displayed.

3

Select measuring mode	enter
Temperature unit	
Calibration medium water/air	
Calibration timer	
CHECK TAG	
CHECK GROUP	

Menu item	Action	Choices
<p>TAG</p> 	<p>Select ON or OFF using ▲ ▼ keys. Press enter to confirm.</p> <p>When switched on, the entry for "TAG" in the Memosens sensor is compared to the entry in the analyzer. If the entries differ, a message will be generated.</p>	<p>ON/OFF</p>
<p>GROUP</p> 	<p>Select ON or OFF using ▲ ▼ keys. Press enter to confirm.</p> <p>Function as described above</p>	<p>ON/OFF</p>



Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated and Sensoface gets "sad". The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Output Current: Range, Current Start/End


(Example: current output 1)



- 1 Press **menu** key.
- 2 Select **CONF** using **◀ ▶**, press **enter**.
- 3 Select **OUT1** menu using **◀ ▶** keys, press **enter**.
- 4 All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.
- 5 Exit: Press **meas** key until the [meas] mode indicator is displayed.

4


Current range	enter
Process variable	enter
Current start	enter
Current end	
Time averaging filter	
Output current during error message	
Output current for Sensoface message	
Output current during HOLD	
Output current for HOLD FIX	

Menu item	Action	Choices
<p>Current range</p> 	<p>Select 4-20 mA or 0-20 mA range using \blacktriangle \blacktriangledown keys.</p> <p>Press enter to confirm.</p>	<p>4-20 mA / 0-20 mA</p>
<p>Process variable</p> 	<p>Example: current output 1, device type OXY</p> <p>Select using \blacktriangle \blacktriangledown keys: OXY: oxygen value TMP: Temperature Press enter to confirm.</p>	<p>OXY/TMP</p>
<p>Current start / end</p> 	<p>Modify digit using \blacktriangle \blacktriangledown keys, select next digit using \blacktriangleleft \blacktriangleright keys.</p> <p>Press enter to confirm.</p>	<p>000.0 ... 0600% (OXY) -20 ... 150 °C / -4 ... 302 °F (TMP)</p>

For **process variables comprising several decades**, decimal point and dimension can be shifted using the \blacktriangleleft \blacktriangleright cursor keys.
 Then, the desired number is entered using \blacktriangle \blacktriangledown and \blacktriangleleft \blacktriangleright . For measurement in gases (GAS), this method is used to switch between ppm and % for volume concentration (10000 ppm = 1 %).


Assignment of measured values: current start and current end

Example 1: Range 0...100%



Example 2: Range 50...70%

Advantage: Higher resolution in range of interest



Output Current: Time Averaging Filter

(Example: current output 1)

1 Press **menu** key.


2 Select **CONF** using **◀ ▶**, press **enter**.

3 Select **OUT1** menu using **◀ ▶** keys, press **enter**.

4 All items of this menu group are indicated by the "OT1:" code. Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

5 Exit: Press **meas** key until the [meas] mode indicator is displayed.

Current range	enter
Process variable	
Current start	
Current end	
Time averaging filter	
Output current during error message	
Output current for Sensoface message	
Output current during HOLD	
Output current for HOLD FIX	


Menu item	Action	Choices
Time averaging filter 	Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0...120 SEC (0000 SEC)

Time averaging filter

To smoothen the current output, a low-pass filter with adjustable filter time constant can be switched on. When there is a jump at the input (100 %), the output level is at 63 % after the time interval has been reached. The time interval can be set from 0 to 120 sec. If the time interval is set to 0 sec, the current output directly follows the input.


Note:

The filter only acts on the current output, not on the display or the limit values! During HOLD the filter is not applied. This prevents a jump at the output.





Output Current: Error and HOLD

(Example: current output 1)




- 1 Press **menu** key.
- 2 Select **CONF** using **◀ ▶**, press **enter**.
- 3 Select **OUT1** menu using **◀ ▶** keys, press **enter**.
- 4 All items of this menu group are indicated by the "OT1:" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.
- 5 Exit: Press **meas** key until the [meas] mode indicator is displayed.




Menu item	Action	Choices
Output current during error message 	The output current can be set to 22 mA in the case of error messages or error messages. Select ON or OFF using ▲ ▼ keys. Confirm by pressing enter	OFF / ON
Output current during Sensoface messages OT1: FACE 22 mA	The output current can be set to 22 mA in the case of Sensoface messages. Select ON or OFF using ▲ ▼ keys. Confirm by pressing enter	OFF / ON
Output current during HOLD 	LAST: During HOLD the last measured value is maintained at the output. FIX: During HOLD a value (to be entered) is maintained at the output. Select using ▲ ▼ keys. Press enter to confirm.	LAST/FIX
Output current for HOLD FIX 	Only with FIX selected: Enter current which is to flow at the output during HOLD. Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	00.00...22.00 mA (21.00 mA)

Output signal during HOLD:



Output Current: Alarm Delay, Sensocheck




Menu item	Action	Choices
<p>Alarm delay</p> 	<p>Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.</p>	<p>0...600 SEC (10 SEC)</p>
<p>Sensocheck</p> 	<p>Select Sensocheck (continuous monitoring of sensor membrane and lines). Select ON or OFF using ▲ ▼ keys. Press enter to confirm. (At the same time, Sensoface is activated. With OFF, Sensoface is also switched off.)</p>	<p>ON/OFF</p>

The alarm delay time delays the color change of the display backlighting to red, the 22 mA signal (if configured), and the alarm contact switching.

Error messages can be signaled by a 22 mA output current. In addition, a relay contact (RELAY1 / RELAY2) can be configured as alarm contact.

Salinity Correction, Pressure Correction







Menu item	Action	Choices
<p>Enter salinity</p> 	<p>Enter the salinity of the process medium. Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.</p>	<p>00.00...45.00 ppt</p>
<p>Enter pressure unit</p> 	<p>Select desired pressure unit using ▲ ▼ keys. Press enter to confirm.</p>	<p>Bar/kPa/PSI</p>
<p>Enter pressure correction</p> 	<p>Select using ▲ ▼ keys: MAN (manual input) Press enter to confirm.</p>	<p>MAN / EXT</p>
<p>Manual pressure input</p> 	<p>Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.</p>	<p>Input range: 0.000...9.999 BAR / 000.0...999.9 KPA / 000.0...145.0 PSI</p> <p>1.013 BAR</p>

Relay Contacts: Function Assignment, Limit Values




- 1 Press **menu** key.
- 2 Select **CONF** using ◀ ▶, press **enter**.
- 3 Select **RELAY1** menu using ◀ ▶ keys, press **enter**.
Specify relay contact function: **LIMIT**.
- 4 All items of this menu group are indicated by the "LM1:" code.
Press **enter** to select menu, edit using arrow keys (see next page).
Confirm (and proceed) by pressing **enter**.
- 5 Exit: Press **meas** key until the [meas] mode indicator is displayed.

Use of relays	enter
Select process variable	↩
Limit 1 switching characteristics (function)	↩
Limit 1 contact type	
Limit 1 setpoint	
Limit 1 hysteresis	
Limit 1 delay	


Menu item	Action	Choices
<p>Use of relays</p> 	<p>Select in the text line using ▲ ▼ keys:</p> <ul style="list-style-type: none"> • Limit function (LIMITS) • Error message (ALARM) • Rinse contact (WASH) <p>Press enter to confirm.</p>	<p>LIMIT / ALARM / WASH</p> <p>Note: The following submenu depends on the selected setting.</p>
<p>Select process variable</p> 	<p>Select desired process variable using ▲ ▼ keys.</p> <p>Press enter to confirm.</p>	<p>OXY/TMP</p>
<p>Limit 1 function</p> 	<p>Select desired function using arrow keys.</p> <p>LoLevel: active if value falls below setpoint HiLevel: active if value exceeds setpoint</p> <p>Press enter to confirm.</p>	<p>Lo LEVEL / Hi LEVEL Limit 1 icon: ▼</p>
<p>Limit 1 contact response</p> 	<p>N/O: normally open contact N/C: normally closed contact</p> <p>Select using ▲ ▼ keys. Press enter to confirm.</p>	<p>N/O / N/C</p>
<p>Limit 1 setpoint</p> 	<p>Enter setpoint using ▲ ▼ ◀ ▶ keys.</p> <p>Press enter to confirm.</p>	<p>Depending on Memosens sensor</p>

Relay Contacts: Limit Function, Hysteresis

(Example: relay 1)




- 1 Press **menu** key.
- 2 Select **CONF** using ◀ ▶, press **enter**.
- 3 Select **RELAY1** menu using ◀ ▶ keys, press **enter**.
Specify relay contact function: **LIMIT**.
- 4 All items of this menu group are indicated by the "LM1:" code.
Press **enter** to select menu, edit using arrow keys (see next page).
Confirm (and proceed) by pressing **enter**.
- 5 Exit: Press **meas** key until the [meas] mode indicator is displayed.




Menu item	Action	Choices
Limit 1 hysteresis 	Select hysteresis using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0...50 % full scale
Limit 1 delay 	The contact is activated with delay (deactivated without delay) Adjust delay using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0 ... 9999 SEC (0010 SEC)

Application of Hysteresis:

Limit Lo




Limit Hi




Relay Contacts: Alarm

(Example: relay 1)



Menu item	Action	Choices
<p>Alarm</p> 	<p>Select error messages (FAIL) or Sensoface messages (FACE) as trigger signal using ▲ ▼ ◀ ▶ keys. Press enter to confirm.</p>	<p>FAIL / FACE</p>
<p>Contact response</p> 	<p>N/O: normally open contact N/C: normally closed contact Select using ▲ ▼ keys. Press enter to confirm.</p>	<p>N/O / N/C</p>



Alarm contact

A relay contact (RELAY1 / RELAY2) can be configured as alarm contact.

Relay Contacts: Controlling a Rinsing Probe

(Example: relay 1)

1 Press **menu** key.


2 Select **CONF** using **◀ ▶**, press **enter**.


3 Select **RELAY1** menu using **◀ ▶** keys, press **enter**.
Specify relay contact function: **WASH**.

4 All items of this menu group are indicated by the "WS1:" code.
Press **enter** to select menu, edit using arrow keys (see next page).
Confirm (and proceed) by pressing **enter**.

5 Exit: Press **meas** key until the [meas] mode indicator is displayed.



Function	enter
Cleaning interval	enter
Cleaning duration	enter
Relax time	
Contact type	

Menu item	Action	Choices
<p>Use of relays</p> 	<p>Select in the text line using ▲ ▼ keys:</p> <ul style="list-style-type: none"> • Limit function (LIMITS) • Error message (ALARM) • Rinse contact (WASH) <p>Press enter to confirm.</p>	<p>LIMIT / ALARM / WASH</p> <p>Note: The following submenu depends on the selected setting.</p>
<p>Cleaning interval</p> 	<p>Adjust value using ▲ ▼ ◀ ▶ keys.</p> <p>Press enter to confirm.</p>	<p>0.0...999.9 h (000.0 h)</p>
<p>Cleaning duration</p> 	<p>Adjust value using ▲ ▼ ◀ ▶ keys.</p> <p>Press enter to confirm.</p> <p>Without figure: Relax time</p>	<p>0...9999 SEC (0060 SEC)</p> <p>Relax time: 0000 ... 1999 SEC (0030 SEC)</p>
<p>Contact type</p> 	<p>N/O: normally open contact N/C: normally closed contact</p> <p>Select using ▲ ▼ keys. Press enter to confirm.</p>	<p>N/O / N/C</p>



Protective Wiring of Relay Contacts


Relay contacts are subject to electrical erosion. Especially with inductive and capacitive loads, the service life of the contacts will be reduced. For suppression of sparks and arcing, components such as RC combinations, nonlinear resistors, series resistors and diodes should be used.



Typical AC applications with inductive load

- 1 Load
- 2 RC combination,
e.g., RIFA PMR 209
Typical RC combinations for
230 V AC:
capacitor 0.1 μF / 630 V,
resistor 100 Ω / 1 W
- 3 Contact

Typical Protective Wiring Measures



- A:** DC application with inductive load
- B:** AC/DC applications with capacitive load
- C:** Connection of incandescent lamps

- A1 Inductive load
- A2 Free-wheeling diode, e.g., 1N4007 (Observe polarity)
- A3 Contact
- B1 Capacitive load
- B1 Resistor, e.g., $8 \Omega / 1 \text{ W}$ at $24 \text{ V} / 0.3 \text{ A}$
- B3 Contact
- C1 Incandescent lamp, max $60 \text{ W} / 230 \text{ V}$, $30 \text{ W} / 115 \text{ V}$
- C3 Contact



WARNING!

Make sure that the maximum ratings of the relay contacts are not exceeded even during switching!

Time and Date, Measuring Point (TAG/GROUP)

1 Press **menu** key.

2 Select **CONF** using **◀ ▶**, press **enter**.

3 Select **CLOCK** or **TAG** using **◀ ▶** keys, press **enter**.

4 All items of this menu group are indicated by the "CLK:" or "TAG" code.
Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

5 Exit: Press **meas** key until the [meas] mode indicator is displayed.

4

enter

Time format

Time

Day and month

Year

TAG of measuring point

GROUP of measuring points

Time and Date

Control of the calibration and cleaning cycles is based on the time and date of the integrated real-time clock.

In measuring mode the time is shown in the lower display. When using digital sensors, the calibration data is written in the sensor head. In addition, the logbook entries (cf Diagnostics) are provided with a time stamp.


Note:

There is no automatic switchover from winter to summer time!
Be sure to manually adjust the time!

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated and Sensoface gets "sad". The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Menu item	Action	Choices
<p>TAG of measuring point</p> 	<p>In the lower display line you can enter a designation for the measuring point (TAG) and for a group of measuring points (GROUP) if applicable. Up to 32 digits are possible.</p> <p>By pressing meas (repeatedly) in the measuring mode you can view the tag number.</p> <p>Select character using ▲ ▼ keys, select next digit using ◀ ▶ keys. Press enter to confirm.</p>	<p>A...Z, 0...9, - + < > ? / @</p> <p>The first 10 characters are seen in the display without scrolling.</p>
<p>GROUP of measuring points</p>	<p>Select number using ▲ ▼ keys, select next digit using ◀ ▶ keys. Confirm by pressing enter</p>	<p>0000 ... 9999 (0000)</p>

Calibration adapts the device to the individual sensor characteristics.

For best performance, you should always calibrate in air.

Compared to water, air is a calibration medium which is easy to handle, stable, and thus safe. In the most cases, however, the sensor must be removed for a calibration in air.

When dealing with biotechnological processes which require sterile conditions, the sensor cannot be removed for calibration. Here, calibration must be performed directly in the process medium (e.g., after sterilization and aeration).

In the field of biotechnology, for example, often saturation is measured and calibration is performed in the process medium for reasons of sterility.

For other applications where concentration is measured (water control etc.), calibration in air has proved to be useful.

Note:

All calibration procedures must be performed by trained personnel. Incorrectly set parameters may go unnoticed, but change the measuring properties.

Common Combination: Process Variable / Calibration Mode

Measurement	Calibration	Application
Saturation	Water	Biotechnology; sensor cannot be removed for calibration (sterility)
Concentration	Air	Waters, open basins

On the following pages, the calibration procedure for a slope calibration in air is described. Of course, other combinations of process variable and calibration mode are possible.

Display	Action	Remark
	Select calibration. Place sensor in air, press enter to start. Device goes to HOLD mode.	“CAL WATER” or “CAL AIR” is selected in the configuration.
	Enter relative humidity using arrow keys Press enter to proceed.	Default for relative humidity in air: rH = 50%
	Enter cal pressure using arrow keys . Press enter to proceed.	Default: 1.013 bar Unit: bar/kpa/PSI
	Drift check: Display of: sensor current (nA), response time (s), temperature (°C/°F) Press enter to proceed.	The drift check can take some minutes.
	Display of calibration data (slope and zero). Press enter to proceed.	
	Display of selected process variable (here: %vol). Now the device is in HOLD mode: Reinstall the sensor and check whether the measure- ment is OK. MEAS exits calibration, REPEAT permits repetition.	After end of calibration, the outputs remain in HOLD mode for a short time.

Display	Action	Remark
 <p>The display shows 'CAL' in large digits, 'CAL WATER' below it, and a 'cal' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Select calibration (SLOPE). Immerse sensor in cal medium, press enter to start.</p>	<p>“CAL WATER” or “CAL AIR” is selected in the configuration.</p>
 <p>The display shows '1000 BAR' in large digits, 'PRESSURE' below it, and a 'cal' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Enter cal pressure Press enter to proceed.</p>	<p>Default: 1.013 bar Unit: bar/kpa/PSI</p>
 <p>The display shows '613 nA' in large digits, '120 5' and '273 C' below it, and a 'cal' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Drift check: Display of: Sensor current (nA) Response time (s) Temperature (°C/°F)</p>	<p>Device goes to HOLD mode. The drift check might take some time.</p>
 <p>The display shows '-59.3 nA' in large digits, 'ZERO -003 nA' below it, and a 'cal' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Display of calibration data (slope and zero) and Sensoface Press enter to proceed.</p>	<p>Related to 25 °C and 1013 mbar</p>
 <p>The display shows '823 ppm' in large digits, 'MEAS REPE' below it, and a 'cal' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Display of selected process value. To exit calibration: Select MEAS ◀ ▶, then enter</p>	<p>To repeat calibration: Select REPEAT ◀ ▶, then enter</p>
 <p>The display shows '822 ppm' in large digits, 'GOOD BYE' below it, and a 'meas' indicator at the bottom. A HOLD icon is in the top right corner.</p>	<p>Place sensor in process. End of calibration</p>	<p>After end of calibration, the outputs remain in HOLD mode for a short time.</p>

Flawless, amperometric oxygen sensors have a low zero current. Therefore, a zero calibration is only recommended for measurement of oxygen traces.

When a zero calibration is performed, the sensor should remain for at least 10 to 30 minutes in the calibration medium (sulfite solution or nitrogen) in order to obtain stable, non-drifting values.

During zero calibration, a drift check is not performed. Zero current of a flawless sensor is notably less than 0.5 % of air current.

Display	Action	Remark
	Select calibration, proceed by pressing enter	
	Ready for calibration. Hourglass blinks. Place sensor in oxygen-free medium	Display (3 sec) Now the device is in HOLD mode.
	Primary display: zero current. Press enter to save this value or correct using arrow keys and then save by pressing enter . Secondary display: currently measured sensor current	Wait for the value to stabilize, can take 10 ... 30 minutes.
	Display of slope Display of new zero current. End calibration by pressing enter key, place sensor in process.	Sensoface display
	The oxygen value is shown in the primary display. To exit calibration: Select MEAS, then enter	To repeat calibration: Select REPEAT, then enter
	End of calibration	After end of calibration, the outputs remain in HOLD mode for a short time.

Calibration by Sampling (One-Point Calibration).

During product calibration the sensor remains in the process.

The measurement process is only interrupted briefly.

Procedure:

During sampling the currently measured value is stored in the device. The device immediately returns to measuring mode. The cal mode indicator blinks and reminds you that calibration has not been terminated. The reference value is measured on the site, e.g., using a portable meter in a bypass.

This value is then entered in the device. The new value for slope or zero is calculated from the stored value and the reference value. From the measured value, the device automatically recognizes whether a new slope or zero must be calculated (above approx. 5 % saturation: slope, below: zero).

If the sample is invalid, you can take over the measured value saved during sampling instead of the reference value. In that case the old calibration values remain stored. Afterwards, you can start a new product calibration. The following describes a product calibration with slope correction – a product calibration with zero correction is performed correspondingly.

Display	Action	Remark
	Select product calibration: P_CAL Press enter to proceed.	If you have protected the calibration with a passcode (in the Service menu), the device will return to measuring mode when an invalid code is entered.
	Ready for calibration. Hourglass blinks. Press enter to proceed.	Display (3 sec)
	Take sample and save value. Press enter to proceed.	Now the sample can be measured in the lab.

Display	Action	Remark
	The device returns to measuring mode.	From the blinking CAL mode indicator, you see that product calibration has not been terminated.
	Product calibration step 2: When the sample value has been determined, open the product calibration once more (P_CAL).	Display (3 sec) Now the device is in HOLD mode.
	The stored value is displayed (blinking) and can be overwritten with the measured sample value. Press enter to proceed.	
	Display of new slope and zero. Sensoface is active. Press enter to proceed.	Related to 25 °C and 1013 mbar To repeat calibration: Select REPEAT, then enter
	Display of new oxy value. Sensoface is active. To exit calibration: Select MEAS, then enter	To repeat calibration: Select REPEAT, then enter
	End of calibration	After end of calibration, the outputs remain in HOLD mode for a short time.

Display	Action	Remark
	Select CAL_RTD calibration method. Press enter to proceed.	Wrong settings change the measurement properties!
	Measure the temperature of the process medium using an external thermometer.	Display (3 sec) Now the device is in HOLD mode.
	Enter the measured temperature value. Maximum difference: 10 K. Press enter to proceed.	Display of actual temperature (uncompensated) in the lower display.
	The corrected temperature value is displayed. Sensoface is active. To exit calibration: Select MEAS, then enter	To repeat calibration: Select REPEAT, then enter
	After calibration is ended, the device will switch to measuring mode.	After end of calibration, the outputs remain in HOLD mode for a short time.

Display



or AM/PM and °F:



Remark

From the configuration or calibration menus, you can switch the device to measuring mode by pressing the **meas** key.

In the measuring mode the upper display line shows the configured process variable (% , mg/l, ppm or temperature), the lower display line shows the time and the second configured process variable (% , mg/l, ppm or temperature). The [meas] mode indicator lights.

Note:

- After prolonged power outage (> 5 days), the time display is replaced by dashes and cannot be used for processing. In that case, enter the correct time.

By pressing the **meas** key you can step through the following displays. When no key has been pressed for 60 sec, the device returns to the standard display, see "Display in Measuring Mode" on page 20.



Further displays (each by pressing **meas**).

- 1) Display of tag number ("TAG")
- 2) Display of time and date (without figure)


In the Diagnostics mode you can access the following menus without interrupting the measurement:

CALDATA	Viewing the calibration data
SENSOR	Viewing the sensor data
SELFTEST	Starting a device self-test
LOGBOOK	Viewing the logbook entries
MONITOR	Displaying currently measured values
VERSION	Displaying device type, software version, serial number


Access to diagnostics can be protected with a passcode (SERVICE menu).

Note:

HOLD is not active during Diagnostics mode!

Action	Key	Remark
Activate diagnostics	 menu	Press menu key to call the selection menu. Select DIAG using ◀ ▶ keys, confirm by pressing enter
Select diagnostics option		Use ◀ ▶ keys to select from: CALDATA SENSOR SELFTEST LOGBOOK MONITOR VERSION See next pages for further proceeding.
Exit	meas	Exit by pressing meas .

Display



Menu item

Displaying the calibration data

Select CALDATA using $\leftarrow \rightarrow$, confirm by pressing **enter**. Use the $\leftarrow \rightarrow$ keys to select from the bottom line of the display (LAST_CAL ZERO SLOPE NEXT_CAL).

The selected parameter is shown in the upper display line.


Press **meas** to return to measurement.

Displaying the sensor data

Manufacturer, type, serial number and last calibration date. In each case Sensoface is active.

Display data using $\leftarrow \rightarrow$ keys, return by pressing **enter** or **meas**.

Display



Menu item

Device self-test

(To abort, you can press **meas.**)

- 1 **Display test:** Display of all segments with changing background colors (white/green/red).
Proceed by pressing **enter**
- 2 **RAM test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Proceed by pressing **enter**
- 3 **EEPROM test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Proceed by pressing **enter**
- 4 **FLASH test:** Hourglass blinks, then display of --PASS-- or --FAIL--
Proceed by pressing **enter**

Display



Menu item

Displaying the logbook entries

Select LOGBOOK using ◀ ▶, press **enter** to confirm.

With the ▲ ▼ keys, you can scroll backwards and forwards through the logbook (entries -00-...-99-), -00- being the last entry.

If the display is set to date/time, you can search for a particular date using the ▲ ▼ keys.

Press ◀ ▶ to view the corresponding message text.

If the display is set to the message text, you can search for a particular message using the ▲ ▼ keys.

Press ◀ ▶ to display the date and time.

Press **meas** to return to measurement.

Display



Display examples:



Menu item

Displaying the currently measured values (sensor monitor)

Select MONITOR using ◀ ▶, press **enter** to confirm. Use the ◀ ▶ keys to select the desired parameter from the bottom line of the display. The selected parameter is shown in the upper display line.

Press **meas** to return to measurement.

Display of directly measured value

(for validation, sensor can be immersed in a calibration solution, for example, or the device is checked by using a simulator)

Display of sensor operating time

Version

Display of **device type, software/hardware version** and **serial number** for all device components.

Use the ▲ ▼ keys to switch between software and hardware version.



Press **enter** to proceed to next device component.

In the Service mode you can access the following menus:

- MONITOR Displaying currently measured values
- OUT1 Testing current output 1
- OUT2 Testing current output 2
- RELAY Testing the relay function
- CODES Assigning and editing passcodes
- DEVICE TYPE Selecting the device type (pH, Oxy, Cond)
- DEFAULT Resetting the device to factory settings


Note:

HOLD is active during Service mode!

Action	Key/Display	Remark
Activate Service		Press menu key to call the selection menu. Select SERVICE using ◀ ▶ keys, press enter to confirm.
Passcode		Enter passcode "5555" for service mode using the ▲ ▼ ◀ ▶ keys. Press enter to confirm.
Display		In service mode the following icons are displayed: <ul style="list-style-type: none"> • HOLD triangle • Service (wrench)
Exit	meas	Exit by pressing meas .

Menu item

Remark

**Displaying currently measured values (sensor monitor) with HOLD mode activated:**

Select MONITOR using ◀ ▶, press **enter** to confirm.
Select the process variable in the bottom text line using ◀ ▶.

The selected parameter is shown in the upper display line.
As the device is in HOLD mode, you can perform validations using simulators without influencing the signal outputs.

Hold **meas** depressed for longer than 2 sec to return to Service menu.

Press **meas** once more to return to measurement.

**Specifying the current for outputs 1 and 2:**

Select OUT1 or OUT2 using the ◀ ▶ keys, press **enter** to confirm.
Enter a valid current value for the respective output using ▲ ▼ ◀ ▶ keys.

Confirm by pressing **enter**.

For checking purposes, the actual output current is shown in the bottom right corner of the display.

Exit by pressing **enter** or **meas**.

**Relay test (manual test of contacts):**

Select RELAIS using ◀ ▶, press **enter** to confirm.

Now the status of the relays is "frozen". The 2 digits of the main display represent the respective states (from left to right: REL1, REL2). The selected digit blinks.

Select one of the relays using the ◀ ▶ keys, close (1) or open (0) using the ▲ ▼ keys.

Exit by pressing **enter**. The relays will be re-set corresponding to the measured value.

Press **meas** to return to measurement.

Menu item	Remark
	<p>Setting the passcodes: In the "SERVICE - CODES" menu you can assign passcodes to DIAG, HOLD, CAL, CONF and SERVICE modes (Service preset to 5555). When you have lost the Service passcode, you have to request an "Ambulance TAN" from the manufacturer specifying the serial number and hardware version of your device. To enter the "Ambulance TAN", call the Service function and enter passcode 7321. After correct input of the ambulance TAN the device signals "PASS" for 4 sec and resets the Service passcode to 5555.</p>
	<p>Reset to factory settings: In the "SERVICE - DEFAULT" menu you can reset the device to factory settings. NOTICE! After a reset to factory setting the device must be reconfigured completely, including the sensor parameters!</p>

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 99	DEVICE FAILURE	Error in factory settings EEPROM or RAM defective This error message only occurs in the case of a total defect. The device must be repaired and recalibrated at the factory.
ERR 98	CONFIGURATION ERROR	Error in configuration or calibration data Configuration or calibration data defective; completely reconfigure and recalibrate the device.
ERR 95	SYSTEM ERROR	System error Restart required. If error still persists, send in the device for repair.
ERR 01	NO SENSOR	Sensor error Device type not assigned Defective sensor Sensor not connected Break in sensor cable
ERR 02	WRONG SENSOR	Wrong sensor
ERR 04	SENSOR FAILURE	Failure in sensor
ERR 05	CAL DATA	Error in cal data
ERR 11	RANGE	Display range violation
ERR 12	MV RANGE	mV range
ERR 13	TEMPERATURE RANGE	Temperature range violation

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 60	OUTPUT LOAD	Load error
ERR 61	OUTPUT 1 TOO LOW	Output current 1 < 0 (3.8) mA
ERR 62	OUTPUT 1 TOO HIGH	Output current 1 > 20.5 mA
ERR 63	OUTPUT 2 TOO LOW	Output current 2 < 0 (3.8) mA
ERR 64	OUTPUT 2 TOO HIGH	Output current 2 > 20.5 mA

Sensoface messages:

Calibration timer expired:	OUT OF CAL TIME CALIBRATE OR CHANGE SENSOR
Sensor zero/slope:	SENSOR ZERO/SLOPE CALIBRATE OR CHANGE SENSOR
Sensor response:	SENSOR DRIFT CALIBRATE OR CHANGE SENSOR
Sensor TAG does not correspond to device entry.	WRONG SENSOR TAG
Sensor GROUP does not correspond to device entry.	WRONG SENSOR GROUP xxxx

Sensocheck, Sensoface Sensor Monitoring



Sensocheck continuously monitors the sensor and its wiring. The three Sensoface indicators provide information on required maintenance of the sensor. Additional icons refer to the error cause. Pressing the **info** key shows an information text.

Note:

The worsening of a Sensoface criterion leads to the devaluation of the Sensoface indicator (Smiley gets “sad”). An improvement of the Sensoface indicator can only take place after calibration or removal of the sensor defect.

Sensoface message

The Sensocheck message is also output as error message Err 15. The alarm contact is active, the display backlighting turns red, output current OUT is set to 22 mA (when configured correspondingly). All other Sensoface message can be output via a contact (relay contacts, alarm --> “FACE”).

Disabling Sensocheck and Sensoface

Sensocheck can be switched off in the configuration menu (then Sensoface is also disabled).

Exception:

After a calibration, a smiley is always displayed for confirmation.

Operating status	OUT 1	OUT 2	REL1/2	Time out
Measure				-
DIAG				60 s
CAL				No
CONF				20 min
SERVICE				20 min
SERVICE OUT 1				20 min
SERVICE OUT 2				20 min
SERVICE RELAY				20 min
Cleaning function				No
HOLD				No

Explanation:

-  as configured (Last/Fix or Last/Off)
-  active
-  manual

Devices

Stratos MS A405N

Stratos MS A405B (operation in hazardous locations, Zone 2)

Order No.

A405N

A405B

Mounting accessories

Pipe-mount kit

ZU 0274

Panel-mount kit

ZU 0738

Protective hood

ZU 0737

M12 socket for sensor connection
with Memosens cable / M12 connector

ZU 0860

Up-to-date information:www.knick.de

Phone: +49 30 80191-0

Fax: +49 30 80191-200

Email: info@knick.de

Oxy input	Memosens (terminals 1 ... 4)	
Data In/Out	Asynchronous interface, RS-485, 9600/19200 Bd	
Power supply	Terminal 1: +3.08 V/10 mA, Ri < 1 ohm, short-circuit-proof	
Operating modes	GAS	Measurement in gases
	DO	Measurement in liquids
	Temperature measurement	-20 ... 150 °C (depending on sensor)
Display ranges	Saturation (-10 ... 80 °C)	0.0 ... 600.0 %
Standard sensor	Concentration (-10 ... 80°C)	0.00 ... 99.99 mg/l
(depending on sensor)	(Dissolved oxygen)	0.00 ... 99.99 ppm
	Volume concentration in gas	0.00 ... 99.99 %vol
Input correction	Pressure correction *	0.000 ... 9.999 bar / 999.9 kPa / 145.0 PSI manually or through current input 0(4) ... 20 mA
	Salinity correction	0.0 ... 45.0 g/kg
Sensor standardization *		
Operating modes *	CAL_AIR Automatic calibration in air CAL_WTR Automatic calibration in air-saturated water CAL_ZERO Zero calibration P_CAL Product calibration CAL_RTD Temperature probe adjustment	
Pressure correction *	Manual 0.000 ... 9.999 bar / 999.9 kPa / 145.0 PSI	
Calibration timer *	Interval 0000 ... 9999 h	
Sensoface	Provides information on the sensor condition Evaluation of zero/slope, response, calibration interval	

* user-defined

HOLD input	Galvanically separated (optocoupler)	
Function	Switches device to HOLD mode	
Switching voltage	0 ... 2 V AC/DC	HOLD inactive
	10 ... 30 V AC/DC	HOLD active
Output 1	0/4 ... 20 mA, max. 10 V, floating (terminals 8 / 9, galvanically connected to output 2)	
Overrange *	22 mA in the case of error messages	
Characteristic	Linear	
Output filter *	PT ₁ filter, time constant 0 ... 120 s	
Measurement error ¹⁾	< 0.25% current value + 0.025 mA	
Output 2	0/4 ... 20 mA, max. 10 V, floating (terminals 9 / 10, galvanically connected to output 1)	
Overrange *	22 mA in the case of error messages	
Characteristic	Linear	
Output filter *	PT ₁ filter, time constant 0 ... 120 s	
Measurement error ¹⁾	< 0.25% current value + 0.025 mA	

^{*)} user-defined

¹⁾ according to IEC 746 Part 1, at normal operating conditions

Relays 1 / 2	Two relay contacts, floating (terminals 14 / 15 / 16)	
Contact ratings	AC < 250 V / < 3 A / < 750 VA DC < 30 V / < 3 A / < 90 W	
Usage	Limit value Alarm Wash	
Limit value	Function	Min or Max
	Setpoint	As desired within range
	Contact response	N/C or N/O
	Hysteresis	User-defined
	Response delay	0000 ... 9999 s
Alarm	Trigger	Failure or Sensoface
	Contact response	N/C or N/O
Wash	Cycle time	0.1 ... 999.9 h
	ON time	0 ... 1999 s
	Contact response	N/C or N/O
Real-time clock	Different time and date formats selectable	
Power reserve	> 5 days	
Display	LC display, 7-segment with icons, colored backlighting	
Primary display	Character height approx. 22 mm, unit symbols approx. 14 mm	
Secondary display	Character height approx. 10 mm	
Text line	14 characters, 14 segments	
Sensoface	3 status indicators (friendly, neutral, sad face)	
Mode indicators	meas, cal, conf, diag Further icons for configuration and messages	
Alarm indication	Display blinks, red backlighting	
Keypad	Keys: meas, info, 4 cursor keys, enter	
Diagnostics		
Calibration data	Calibration date, zero, slope	
Device self-test	Automatic memory test (RAM, FLASH, EEPROM)	
Display test	Display of all segments	
Logbook	100 events with date and time	

Service functions

Current source	Current specifiable for output 1 and 2 (00.00 ... 22.00 mA)
Sensor monitor	Display of direct sensor signals (mV/temperature/operating time)
Relay test	Manual control of relay contacts
Data retention	Parameters, calibration data, logbook > 10 years (EEPROM)

Electrical safety

Protection against electric shock by protective separation of all extra-low-voltage circuits against mains according to EN 61010-1

Explosion protection (A405B)

see Control Drawing or www.knick.de

EMC

EN 61326

Emitted interference Class B (residential environment)

Immunity to interference Industrial environment

RoHS conformity

according to EC directive 2002/95/EC

Power supply

80 V (-15%) ... 230 (+10%) V AC ; approx. 15 VA ; 45 ... 65 Hz
24 V (-15%) ... 60 (+10%) V DC ; 10 W
Overvoltage category II, protection class II

Nominal operating conditions

Ambient temperature -20 ... +55 °C / -4 ... +131 °F

Transport/Storage temperature -30 ... +70 °C / -22 ... +158 °F

Relative humidity 10 ... 95 % not condensing

Enclosure

Molded enclosure made of PBT/PC, glass fiber reinforced

Mounting Wall, pipe/post or panel mounting

Color Gray, RAL 7001

Ingress protection IP 67 / NEMA 4X outdoor (with pressure compensation)

Flammability UL 94 V-0

Dimensions H 148 mm, W 148 mm, D 117 mm

Control panel cutout 138 mm x 138 mm to DIN 43 700

Weight 1.2 kg (1.6 kg incl. accessories and packaging)

Cable glands 3 knockouts for M20 x 1.5 cable glands
2 knockouts for NPT ½" or rigid metallic conduit

Connections Terminals, conductor cross section max 2.5 mm²,
recommended torque 0.5 ...0.6 Nm

A

- Accessories 78
- Adjusting the temp probe 64
- Alarm delay 40
- Alarm, relay contacts 48
- Ambulance TAN 73
- Assembly 8

B

- Backlighting 19
- Buttons and functions 18

C

- Cable glands 7
- Cables for Memosens 15
- CALDATA 67
- Calibration 56
- Calibration data, display 67
- Calibration medium, selecting 31
- Calibration timer 31
- Calibration with sampling 62
- Capacitive loads, protective wiring of relay contacts 52
- CD-ROM 6
- Certificates 6
- Configuration, alarm delay 40
- Configuration, current output 34
- Configuration, measuring point (TAG/GROUP) 54
- Configuration, menu structure 25
- Configuration, output current 34
- Configuration, overview 28
- Configuration (Oxy) 30
- Configuration, pressure correction 42
- Configuration, relay contacts 44
- Configuration, salt correction 42
- Configuration, Sensocheck 40
- Configuration, sensor verification (TAG, GROUP) 32
- Configuration, time and date 54
- Configuration, time averaging filter 36
- Connecting a Memosens sensor, menu 26
- Connecting a Memosens sensor, terminal assignments 13
- Controlling a rinsing probe via relay contacts 50

- Current calibration data, display 67
- Currently measured values (sensor monitor) 70
- Currently measured values (sensor monitor), display with HOLD activated 72
- Current output, configuration 34
- Current source 72

D

- Date and time, usage 55
- Date, display 65
- Date, setting 54
- Device self-test 68
- Device type, display 70
- Device type Oxy, configuration 30
- Diagnostics, calibration data 67
- Diagnostics, device self-test 68
- Diagnostics, logbook 69
- Diagnostics mode 66
- Diagnostics, sensor data 67
- Diagnostics, sensor monitor 70
- Diagnostics, version 70
- Dimensions 9
- Disabling Sensocheck 41
- Display 19
- Display backlighting 19
- Display, icons 19
- Displaying the time/date 65
- Display in measuring mode 20
- Display, selecting the main display 20
- Display test 68
- Disposal 5
- Documentation 6

E

- EEPROM test 68
- Enclosure components 8
- Enclosure, mounting possibilities 7
- ERR 74
- Error and HOLD, output current 38
- Error messages 74

F

Factory setting 73
FLASH test 68

G

GROUP of measuring points 55

H

Hardware version, display 70
HOLD, configure output current 38
HOLD, exit 23
HOLD, external activation 23
HOLD mode 23
HOLD, output signal 23
HOLD, output signal response 23
Hose clamps 10
Hysteresis of relay contacts 46

I

Icons 19
Inductive loads, protective wiring of relay contacts 52
Info text 74
Introduction 7

K

Keys and functions 18

L

Limit values (relay contacts) 44
LOGBOOK 69
Logbook entries, display 69
Loss of passcode 73

M

- MAIN DISPLAY 20
- Manual pressure input 42
- Measured values, display 70
- Measuring function (device type) 71
- Measuring mode 65
- Measuring point (TAG/GROUP) 54
- Measuring range and output current 35
- Memosens cable (specifications, order code) 15
- Memosens sensor (connection, menu) 26
- Memosens sensor (connection, terminal assignments) 13
- MemoSuite software for calibrating Memosens sensors 14
- Menu structure 24
- Menu structure, configuration 25
- Mounting accessories 9
- Mounting accessories, product range 78
- Mounting plan 9

O

- Operating modes 22
- Operating mode, selection 21
- Operating states 77
- Operation, general 17
- Order codes 78
- Output current, alarm delay, Sensocheck 40
- Output current during Error and HOLD 38
- Output current, fixed value 72
- Output current, range 35
- Output current, time averaging filter 36
- Output filter, time interval 36
- Output signal during HOLD 39
- Output signal during HOLD, overview 23
- Overview of configuration 28
- Oxygen measurement, configuration 31

P

- Package contents, complete 8
- Package contents, documentation 6
- Panel mounting 11
- Passcode lost 73
- Passcodes, setting 73
- Post/pipe mounting 10
- Power supply, connection 13
- Power supply, specifications 82
- Pressure correction 42
- Process variable selection 35
- Product calibration 62
- Product line 78
- Protective hood 10
- Protective wiring of relay contacts 52

Q

- Quickstart guides 6

R

- RAM test 68
- Rating plates 12
- Relay 44
- Relay contact delay 46
- Relay contacts, alarm 48
- Relay contacts, controlling a rinsing probe 50
- Relay contacts, function assignment, limit values 44
- Relay contacts, protective wiring 52
- Relay test (manual test of contacts) 72
- Replacing a Memosens sensor 27
- Reset to factory settings 73
- Return of products under warranty 5
- Rinsing probes, activating 50

S

- Safety information 6
- Salinity correction 42
- Selecting the device type 71
- Sensocheck, configuration 41
- Sensocheck, description 76
- Sensoface, configure output current 39
- Sensoface, description 76
- Sensoface messages, overview 75
- Sensor data, display 67
- Sensor monitor, diagnostics 70
- Sensor monitor, Service 72
- Sensor replacement 27
- Sensor verification (TAG, GROUP) 32
- Serial number, display 70
- Series resistors 52
- Service life of contacts 52
- Service mode 71
- Service passcode lost 73
- Service, relay test 72
- Service, reset to factory settings 73
- Service, sensor monitor 72
- Service, setting the passcodes 73
- Service, specify output current 72
- Signal colors 19
- Slope calibration, calibration medium 30
- Slope calibration in air 58
- Slope calibration in water 59
- Software version, display 70
- Specifications 79
- Specifications, Memosens cable 15
- Specific test report 6
- Specifying the output current 72
- Start-up 14
- Switching characteristics (function) 44

T

- Tag number, display 65
- TAG of measuring point 55
- Technical data 79
- Temperature probe adjustment 64
- Temperature unit 30
- Terminal assignments 13
- Terminals 12
- Time and date, usage 55
- Time averaging filter 37
- Time, display 65
- Time format, setting 54
- Time, setting 54

U

- Use of relays 44

V

- Viewing parameters 65

W

- Weather protector 10
- Wiring 13
- Wrench icon 71

Z

- Zero calibration 60
- ZU 0274 pipe-mount kit 10
- ZU 0737 protective hood 10
- ZU 0738 panel-mount kit 11

Knick
Elektronische Messgeräte GmbH & Co. KG

Beuckestraße 22
14163 Berlin
Germany

Phone: +49 30 80191-0
Fax: +49 30 80191-200
Web: www.knick.de
Email: info@knick.de

Stratos MS A405: Oxygen Measurement

TA-212.100-oxy-KNE03 20170831



092753

Software version: 1.x